

Installation Operation and Maintenance Manual

Impact Trimmer Models

10039

10040

10041

10042

10051

10080

Spinoff Trimmer

This manual is not to be reproduced xerographically or by any other means without expressed written permission from Johnson, Controls, Inc., Plastics Machinery Division

**COPYRIGHT © 1995
Johnson Controls, Inc.
Plastics Machinery Division
10501 Highway M-52
Manchester, MI 48158
800/666-8852**

PN-2501760

CONTENTS

SECTION 1 INTRODUCTION

1.1 Introduction 1-1

1.2 How This Manual Is Organized 1-1

1.3 Machine Warranty 1-1

1.4 Statement of Limited Liability 1-2

1.5 Express Contract of Indemnification 1-3

1.6 Statement of Policy Concerning Occupational Safety and Health Act 1-3

SECTION 2 SAFETY

2.1 Introduction 2-1

2.2 Notes and Warnings 2-2

2.3 General Precautions and Personal Safety 2-2

2.4 Safety Signs 2-3

SECTION 3 SYSTEM DESCRIPTION—IMPACT TRIMMERS (MODELS 10039, 10040, 10041, 10042, 10051 AND 10080)

3.1 Installation and Setup 3-1

 3.1A Leveling the Trimmer 3-1

 3.1B Electrical Connection 3-1

 3.1C Pneumatic Connection 3-1

3.2 Sequence of Operation 3-1

3.3 Operating Controls and Electrical 3-2

 3.3A Automatic Operation 3-4

 3.3B Manual Operation 3-4

3.4 Operation and Maintenance Safety 3-4

 3.4A Pinch Points 3-4

 3.4B Guarding System 3-4

 3.4C Electrical 3-6

 3.4D Obstruction in the Trimmer 3-6

3.5 Options 3-6

Table of Contents

3.6	Mechanical Maintenance	3-8
	3.6A Trimmer Maintenance	3-9
	3-6B Installation Date-Direct Acting Brake - Size XH	3-9
	Direct Acting Brake Disassembly and repair Steps 1 to 5	3-10
	3.6C Chain and Belt Adjustment	3-12
	Bucket Chain Adjustment	3-12
	Platen Chain Adjustment	3-15
	Idler Sprocket Adjustment	3-15
	Drive Belt Adjustment	3-15
	Index Chain Adjustment Model 10039-10042	
	Single and Double Index & 10080	3-15
	Bucket Chain Idler Adjustment Model 10041, 10042 Triple Index	3-17
	Jack Shaft Chain Adjustment Model 10041 Triple Index.....	3-17
	3.6D Trimmer Timing	3-19
	Trimmer Timing Procedure 10039-10042 Single and Double Index	3-19
	Timing Procedure 10041 Triple Index	3-20
	Trimmer Timing Procedure 10080 Trimmer	3-21
	Retiming the 10039-10041, 10042, 10080	3-22
	Trimmer Timing Procedure 10051 Single and Double Index	3-23
	Retiming the 10051 Hydraulic Trimmer	3-24
	10051 Hydraulic Pressure Setup	3-24
	3.6E Adjusting Trim Tooling.....	3-24
3.7	Pneumatic Maintenance	3-28
	3.7A Blow/Push-off System	3-28
	3.7B Leak Detector System	3-28
	3.7C Leak Detector Adjustment	3-28